

# P5-16...R40-17

**Model: B01**

## **en** Assembly and Operating Instructions

### **Roller shutter drive with integrated radio transceiver**

Important information for:

- Fitters / • Electricians / • Users

Please forward accordingly!

These instructions must be kept safe for future reference.

2010 300 564 0 16/09/2022



## Table of contents

General .....	3
Warranty .....	3
Safety instructions .....	4
Instructions for the user .....	4
Instructions for installation and commissioning.....	4
Intended use .....	5
Assembling and disassembling the plug-in connecting cable.....	6
Assembly .....	7
Preparation for Commissioning .....	9
Checking that the running direction is correct.....	10
Confirming the drive .....	10
Limit position settings and configurations.....	11
Obstacle detection.....	11
Disposal .....	11
Maintenance .....	12
Technical data dia. 35 .....	12
Technical data dia. 45 .....	12
What to do if...? .....	13
Sample wiring diagram .....	14
Declaration of conformity .....	15

## General

These tubular drives are high-quality products with the following features:

- Optimised for roller shutter operation
- Can be operated with any suitable KNX transmitter
- Individual, group and central radio control
- No need to run wires to a switch or relay control device
- Any combination of drive and transmitter possible
- Simple to set the limit positions with the transmitter
- Installation without stops possible (from upper point to lower point)
- Two freely selectable intermediate positions can be set
- Flexible radio grouping; can be altered at any time with no need to install/uninstall
- Integrated memory function facilitates easy programming of one or two switching times on daily repeat.
- Automatic detection of the lower limit position when using springs in conjunction with the "drive adapter for obstacle detection"
- Automatic detection of limit positions thanks to intelligent electronic system with stop systems
- Obstacle detection, even when using anti-lifting devices (axle shaft devices)
  - Secure anti-lifting device
  - Slight pressure applied to the roller shutter curtain makes it difficult to raise or reach under it
  - Suitable for rigid aluminium, steel and wooden profiles
- The limit positions do not have to be reset: Changes in the shading solution are accommodated automatically when using stop systems.
- Torque control in the up direction prevents damage to the roller shutter in the event of a frozen or blocked shutter
- Anti-freeze mechanism in the upper limit position can be enabled
- Considerably lower stop load, and thus considerably lower shading solution load.
- Smooth operation of the system and the drive increases the service life
- For plug-in connecting cable
- Fly screen protection function

Please observe these Assembly and Operating Instructions when installing and setting the equipment.



The date of manufacture comes from the first four digits of the serial number.

The numbers 1 and 2 indicate the year and the numbers 3 and 4 indicate the calendar week.

Example: 34th calendar week in 2020

Ser. No.:	2034XXXXX
-----------	-----------

### Explanation of pictograms

	<b>CAUTION</b>	CAUTION indicates a hazardous situation which, if not avoided, could result in injury.
	<b>ATTENTION</b>	ATTENTION indicates measures that must be taken to avoid damage to property.
		Denotes user tips and other useful information.

## Warranty

Structural modifications and incorrect installation which are not in accordance with these and our other instructions can result in serious injuries, e.g., crushing of limbs. Therefore, structural modifications may only be carried out with our prior approval and strictly in accordance with our instructions, particularly the information contained in these Assembly and Operating Instructions. Any further processing of the products which does not comply with their intended use is not permitted.

The end product manufacturer and fitter have to ensure that all the relevant current statutory, official and, in particular, EMC regulations are adhered to during utilisation of our products, especially with regard to end product manufacture, installation and customer advice.



## Safety instructions

The following safety instructions and warnings are intended to avert hazards and to prevent property damage and personal injury.

### Instructions for the user

#### General information

- The drive must be disconnected from its power source during cleaning and maintenance and when replacing parts.
- All work, including maintenance and cleaning, on electrical installations as well as other system parts must always be performed by trained technicians, in particular qualified electricians.
- Children from the age of 8 years and persons with reduced physical, sensory or mental capabilities or lack of experience and/or knowledge may use these devices, provided they are supervised or have been instructed in the safe use of the device, and have understood the hazards involved. Children must not play with the device.
- Systems have to be checked regularly by authorised specialists for wear and damage.
- Always put damaged systems out of operation immediately until they are repaired by an authorised specialist.
- Do not operate equipment if people or objects are within the danger zone.
- Observe the danger zone of the equipment during operation.
- Ensure that there is adequate clearance (at least 40 cm) between moving parts and adjacent objects.



#### Caution

##### Safety instructions for avoiding serious injuries.

- **Crushing or shearing points must be avoided or protected.**

### Instructions for installation and commissioning

#### General information

- Observe the safety instructions in EN 60335-2-97. Please note that this list of safety instructions is not exhaustive, since it would be impossible for the standard to include all sources of danger. For example, the design of the operated product, the way the drive works in the situation it is installed in or even the way the end product is mounted in the end user's place of use cannot be taken into consideration by the drive manufacturer.  
If any questions or uncertainties regarding the safety instructions contained in the standard arise, please contact the manufacturer of the part or end product in question.
- All applicable standards and regulations for electrical installation must be complied with.
- All work, including maintenance and cleaning, on electrical installations as well as other system parts must always be performed by trained technicians, in particular qualified electricians.
- Only use spare parts, tools and accessory devices which have been approved by the drive manufacturer.  
Unapproved third-party products or modifications to the system and its accessories represent a risk to your safety and the safety of others. This means that the use of unapproved third-party products, or modifications which have not been agreed with or approved by us, are prohibited. We do not accept liability for damage or injury arising from such actions.
- Position switch with OFF presetting within sight of the driven product, but away from moving parts, at a height of over 1.5 m. This must not be publicly accessible.
- Permanently mounted control devices must be positioned where they can be seen.
- Rated torque and duty cycle must be suitable for the requirements of the driven product.  
Technical data - rated torque and service life can be found on the type plate of the tubular drive.
- Hazardous moving parts of the drive must be installed at a height of over 2.5 m above floor level or any other surface from which the drive can be accessed.
- To ensure safe operation of the system after commissioning, the limit positions must be correctly set/programmed in.
- Drives with a H05VV-F connecting cable may only be used indoors.
- Drives with a H05RR-F, S05RN-F or 05RN-F connecting cable may be used both indoors and outdoors.
- To connect the drive to the driven part, solely mechanical accessory components made by the drive manufacturer from the current product catalogue may be used. The components must be installed in accordance with the manufacturer's instructions.

- If the drive is used for shading solutions in a specially marked area (e.g., escape routes, hazard zones, safety areas), compliance with all applicable regulations and standards must be ensured.
- Once the drive has been installed, the fitter must mark the used tubular drive in the “Technical data” chapter and make a note of the installation position.



### Caution

#### Safety instructions for avoiding serious injuries.

- **When electrical or electronic equipment and units are operated, certain components, e.g., the power supply unit, are live. Physical injuries or damage to property can result in the event of unauthorised interventions or failure to heed warnings.**
- **Be careful when touching the tubular drive, as it heats up during operation for technical reasons.**
- **Before installation, shut down all lines and control devices that are not essential for operation.**
- **Crushing or shearing points must be avoided or protected.**
- **When installing the drive, all-pole disconnection from the mains with a contact gap of at least 3 mm per pole must be provided (EN 60335).**
- **If the mains connecting cable is damaged, it may only be replaced by the manufacturer. If the drive has a plug-in connecting cable, it must be replaced with the same type of mains connecting cable, which is available from the drive manufacturer.**

### Attention

#### Safety instructions for avoiding property damage.

- **Ensure that there is adequate clearance between moving parts and adjacent objects.**
- **The drive must not be carried by the mains connecting cable.**
- **All latching connections and fastening screws on the brackets must be checked to ensure that they are secure.**
- **Ensure that nothing rubs against the tubular drive, such as shading solution attachments, screws, etc.**
- **The drive must be fitted horizontally.**

## Intended use

The type of tubular drive described in these instructions is intended solely for the operation of roller shutters. This type of tubular drive is compatible with the B-Tronic control program and suitable control units with bidirectional KNX radio.

This type of tubular drive supports not only curtain attachment by means of springs but also mechanical anti-lifting devices (e.g., Zurfluh-Feller, Simu, GAH Alberts and Deprat). These are detected automatically.

If the springs or the top lath are screwed or riveted to the barrel, a point must be set in the lower limit position.

For sun protection applications, please use only the types of tubular drive designed for this purpose.

This type of tubular drive is designed for use in single systems (one drive per barrel).

The tubular drive must not be used in potentially explosive areas.

The connecting cable is not suitable for transporting the drive. Always carry the drive by the housing tube.

Other applications, uses and modifications are not permitted in order to protect the safety of the users and others, since these actions can impair the system's safety and carry the risk of personal injury and property damage. The drive manufacturer does not accept liability for damages or injury arising from such actions.

Always observe the information in these instructions when operating or repairing the system. The drive manufacturer does not accept liability for damage or injury resulting from improper usage.

### Attention

**Only use anti-lifting devices if the roller shutter laths are sufficiently strong. The closed curtain must not project beyond the guide tracks or else there is a risk of the joint between the top two laths being subjected to excessive strain and getting damaged.**



## Assembling and disassembling the plug-in connecting cable



### Caution

The power supply to the connecting cable must be disconnected prior to assembly/disassembly.

### Assembling the plug-in connecting cable

Ø35/Ø45/Ø58	
	<p>Insert the <b>dead</b> connecting cable into the drive head until the locating lug clicks into place in the drive. If necessary, use a suitable flathead screwdriver to assist with insertion. Set the screwdriver into one of the two plug grooves provided for this purpose.</p> <p>Check that the cable is properly engaged.</p>
1 = locating lug	

### Disassembling the plug-in connecting cable for tubular drives

Ø35	
	<p>Insert a suitable flathead screwdriver between the locating lug and the snap-in pin, so that the snap-in pin releases the locating lug from the plug.</p> <p>Now you can pull out the connecting cable along with the flat-head screwdriver.</p>
A = snap-in pin	
Ø45/Ø58	
	<p>Insert a suitable flathead screwdriver right into the recess of the locating latch, so that the latch releases the locating lug from the plug.</p> <p>Now you can pull out the connecting cable along with the flat-head screwdriver.</p>
A = locating latch	

## Assembly

### Assembling the drive

#### Attention

To connect the drive to the driven part, solely mechanical accessory components made by the drive manufacturer from the current product catalogue may be used.


Prior to mounting, the fitter must ensure that the masonry and the system being motorised are sufficiently robust (drive torque plus weight of the shading solution).



#### Caution

Electrical connections may only be carried out by a qualified electrician. Prior to assembly, the power supply must be disconnected and secured. Please give the enclosed connection information to the responsible electrical contractor.

If you want the roller shutter curtain to open to the upper stop, proceed as follows: The roller shutter curtain must be prevented from being drawn into the shutter box with a mechanical stop or an angled end strip. With face-fixed elements, we recommend concealed stops in the guide tracks.



Calculate the space required at the side (M) by measuring the drive head (1) and wall bracket (2). The clear dimension of the box (X) minus the space required at the side (M) and idler (G) gives the length (L) of the barrel:  $L=X-M-G$ .


The space required at the side (M) varies depending on the combination of drive and wall bracket.

Then mount the wall bracket and idler. Ensure that the barrel is aligned at right angles to the wall and that sufficient axial play is allowed for the mounted system.

#### Attention

When using rigid shaft connectors, closed brackets must be fitted. The tubular drive presses the closed curtain down to make it difficult for people to reach under it or raise it. Only use curtains made of sufficiently strong material, such as aluminium, steel or wood. To prevent damage to the curtain it must run in guide tracks from top to bottom.

### Assembling and disassembling the mounting pin



Ø45


When pushed in, the mounting pin (2) locks automatically. To undo the mounting pin (2), push the tab washer (1) upwards and pull out the mounting pin (2).







If you wish to use the "obstacle detection" function, you must use the "drive adapter for obstacle detection".




### Assembling and disassembling the drive adapter

#### Fitting the ring onto the thrust ring



<b>Assembling the drive adapter with safety catch on the drive shaft</b>	<b>Disassembling the drive adapter with safety catch on the drive shaft</b>
	
<b>Assembling and disassembling the drive adapter with drive adapter safety catch or screw connection</b>	
 <p data-bbox="287 461 764 602">Assembling and disassembling the drive adapter with separate drive adapter safety catch</p>	 <p data-bbox="1000 461 1487 602">Assembling and disassembling the drive adapter with screw connection</p>

## Mounting the drive in the tube


	<p><b>For profile shafts:</b></p> <p>In the case of some drive adapters, tolerances of the groove widths in different barrels can be offset by rotating the drive adapter into a different groove recess. These groove recesses have different sizes and allow the drive to fit exactly.</p>
	<p><b>For round shafts:</b></p> <p>Measure the lug of the thrust ring (X, Y). Then notch the tube on the motor side, so the lug of the thrust ring can also be pushed into the shaft. There must be no play between the lug of the thrust ring and the shaft.</p>
	<p>To ensure secure torque transmission for <b>round shafts</b>, we recommend screwing the drive adapter to the shaft (see the table below).</p> <p><b>Attention! When drilling into the barrel, never drill near the tubular drive!</b></p>

Size of drive [mm]	Drive adapter	Torque max. [Nm]	Fastening screws (4 units)
dia. 35-dia. 45	All	Up to 50	Self-tapping screw dia. 4.8 x 9.5 mm


We also recommend screwing the idler to the barrel.

**Attention**

**Do not hammer the tubular drive into the tube or drop it into the barrel! The curtain can only be secured using springs or rigid shaft connectors. We recommend at least three pieces per metre of barrel.**

	<p>Assemble the tubular drive with the relevant ring (1) and drive adapter (2). If the ring has several grooves, select the groove which is a perfect fit and push the ring (1) onto the thrust ring.</p> <p>Insert the tubular drive with the pre-assembled ring (1) and drive adapter (2) into the tube to achieve a form fit. Ensure that the ring and drive adapter are secure in the tube.</p> <p>Mount the assembled unit comprising shaft, tubular drive and idler on the box and secure the drive with a splint or spring pin according to the type of wall bracket fixing.</p>
--	---

Position the barrel so that the roller shutter curtain can be attached with springs or fit the rigid shaft connectors in accordance with the manufacturer's instructions.

	<p><b>Lay the connecting cable</b></p> <p>Lay the connecting cable up to the tubular drive, and fix The connecting cable and any antennae must not project into the winding chamber. Cover any sharp edges.</p>
--	---



## Preparation for Commissioning

The tubular drive can be operated with any suitable KNX transmitter  
 The commissioning (e.g. setting the limit positions etc.) and later configurations are, however, only possible with a B-Tronic transmitter.

**i** **The running direction must be correct. When setting the limit positions, the tubular drive runs with the limit position status indicator. The upper limit position must always be set first. When setting the upper limit position, ensure that the roller shutter curtain is not pulled out of the guide tracks.**

**When first installing, using springs and adjusting the limit position ‘...to lower stop’, the barrel in the lower limit position turns approx. 1/4 of a turn further than usual. In doing so, the tubular drive is able to detect the use of anti-lifting devices or springs automatically. The tubular drive switches off automatically.**


### Limit position status indicator

A brief stopping and restarting indicates that no limit position has been set in that direction of movement.

### Completion of installation following automatic setting of limit positions


The drive saves the limit position permanently once the upper limit position is reached 3 times in succession. Installation is then complete. If the limit position is set above a point, this is stored permanently.

### Explanation of symbols



**1 = direction switch**  
**2 = radio switch**

230V AC / 50 Hz



### Connecting the tubular drive



Connect the tubular drive to the power supply.

1 = blue	3 = black
2 = brown	4 = green-yellow

**i** **If several tubular drives are to be connected in parallel, you can deactivate the programming mode on one tubular drive by switching the radio switch to the outside position after turning the power on. If the radio switch is already in this position, switch it to the inside and back to the outside position.**



## Readying the tubular drive for programming

	<b>Readying the tubular drive for programming by switching on the power</b> Switch on the power. ► The tubular drive is ready to program for 3 minutes
	<b>Readying the tubular drive for programming with the radio switch</b> Switch the radio switch to the inside position. If the radio switch is already in this position, switch it to the outside and back to the inside position. ► The tubular drive is ready to program for 3 minutes
	<b>Put the tubular drive into programming mode with a programmed B-Tronic transmitter</b> Please find the appropriate description in the instructions for the B-Tronic transmitter.

## Checking that the running direction is correct





**The direction of rotation can only be changed if no limit position has been set.**

Press the UP or DOWN button

- The shading solution runs in the desired direction.
- Direction switch is OK.

If the shading solution runs in the wrong direction, the running direction must be switched. Proceed as follows:



Switch the direction switch (1) to the opposite position.

- The shutter direction is now changed.

Check the shutter direction again.

## Confirming the drive

The drive confirms each programming and deletion action. The tubular drive does this through a small movement that can be perceived (audibly) as "clicking" or (visually) as "shifting".

## Limit position settings and configurations

The commissioning (e.g. setting the limit positions etc.) and later configurations are only possible with a B-Tronic transmitter. Please find the appropriate description in the instructions for the B-Tronic transmitter.

### Attention

**When operating the tubular drive without the drive adapter for obstacle detection, if using springs a point must be set in the lower limit position.**

### Possible limit position settings

- Upper stop to lower stop
- Upper point to lower point
- Upper stop to lower point
- Upper point to lower stop

The limit position becomes fixed after the tubular drive has turned off **automatically** in the desired position three times.

### Possible configurations

- Intermediate positions I+II
- Memory function
- Upper anti-freeze mechanism
- Fly screen protection function
- Repeater mode

## Obstacle detection



### Caution

**Obstacle detection is only active in conjunction with the “drive adapter for obstacle detection”.**

**In addition, please note that the drive must be pushed in to the shaft as far as the band of the thrust ring.**

**Use of the drive’s obstacle detection system as personal protection is not permitted. It has been designed exclusively to protect the roller shutters or sun protection system from being damaged.**

If the drive is correctly installed, it switches off when it detects obstructions or shutter faults and reverses a short way in the opposite direction.

The following are detected:

#### In the **DOWN** direction

- A curtain jam when closing due to objects on the window sill or sticking of the lateral guide tracks.

#### In the **UP** direction

- Extremely large increase in the load (e.g., ice on the end strip)

To ensure that the roller shutter curtain safely enters the guide tracks, obstacle detection is inactive for approx. 1.5 revolutions of the barrel from the upper limit position.

To ensure complete closing of the roller shutter curtain at the lower limit position, the curtain does not reverse once it gets to approx. 260° (dia. 35) and 210° (dia. 45) from the lower limit position.

## Disposal



The crossed-out bin symbol on the product indicates that the device is subject to mandatory disposal separate from household waste. This product must be handed over to a collection point for electrical and electronic equipment at the end of its service life. The packaging material must be disposed of properly.



## Maintenance

These drives are maintenance-free.

### Technical data dia. 35

Tubular drive	P5-16	P9-16
Model	B01	
Type	PROF+ KNX	
Rated torque [Nm]	5	9
Output speed [rpm]	16	16
Limit switch range	64 revolutions	
Supply voltage	230 V AC / 50 Hz	
Connected load [W]	85	110
Rated current consumption [A]	0.36	0.47
Mode	S2 4 min	
Degree of protection	IP 44	
Min. tube inside diameter [mm]	37	
Frequency	868.3 MHz	
Max. number of transmitters	25	
Emission sound pressure level [dB(A)]	≤ 70	

### Technical data dia. 45

Tubular drive	R8-17	R12-17	R20-17	R30-17	R40-17
Model	B01				
Type	PROF+ KNX				
Rated torque [Nm]	8	12	20	30	40
Output speed [rpm]	17	17	17	17	17
Limit switch range	64 revolutions				
Supply voltage	230 V AC / 50 Hz				
Connected load [W]	100	110	160	205	260
Rated current consumption [A]	0.45	0.5	0.75	0.9	1.15
Mode	S2 4 min				
Degree of protection	IP 44				
Min. tube inside diameter [mm]	47				
Frequency	868.3 MHz				
Max. number of transmitters	25				
Emission sound pressure level [dB(A)]	≤ 70				

## What to do if...?

Problem	Remedy
Tubular drive does not move.	Program new transmitter.
	Bring transmitter within range of the tubular drive.
	Insert battery/batteries correctly in the transmitter or insert new battery/batteries.
	Check electrical connection.
	Thermal protection switch in tubular drive has tripped. Wait until the thermal protection switch in the tubular drive is reactivated.
Running direction on tubular drive cannot be set.	Delete limit positions and reset the running direction.
Incorrect running direction after deleting limit positions.	Use the direction switch on the tubular drive to change the direction of rotation.
Tubular drive stops arbitrarily; cannot be restarted in the same direction.	Tubular drive has detected an increase in load. Briefly run the curtain in the opposite direction, then continue in the desired direction.
	Tubular drive is overloaded. Use a higher-torque tubular drive.
	Delete limit positions, then reprogram limit positions.
Tubular drive does not operate at the set switching time.	Use a B-Tronic transmitter to switch the tubular drive into automatic mode.
During the programming run, the drive stops short of the limit position to be programmed.	For safety reasons, the drive reacts sensitively to sluggishness during the programming run, in order to prevent damage. Briefly run curtain DOWN and subsequently UP until you reach the upper limit position.
Ventilation slots of the roller shutter do not close fully.	Delete the limit positions (see Deleting limit positions) then set the limit positions as per "to lower point" (see Setting the limit positions); in this case, set the lower limit position first (lower point) followed by the upper limit position.





## Declaration of conformity

BECKER-ANTRIEBE GMBH  
Friedrich-Ebert-Str. 2 - 4  
35764 Sinn, Germany



**BECKER**

– Original –

### EU Declaration of Conformity

Document No./ Month.Year: **K005/12.21**

We hereby declare that the following product series

Product designation: **Tubular motor**  
Type designation: **P5/16.., P5/20.., P5/30.., P9/16..,  
R8/17.., R12/17.., R20/17.., R30/17.., R40/17.., R50/11..,  
L50/17.., L60/11.., L60/17.., L70/17.., L80/11.., L80/17..,  
L120/11..**  
Version: **C, R, S, F, P, E, O, KNX, PLUS, EN, A0...Z9, +**  
From serial number: **from 220100001**

complies with the applicable regulations of the following Directives:

**Directive 2006/42/EG (MD) L157, 09.06.2006**

**Directive 2014/53/EU (RED) L153, 22.05.2014**

**Directive 2011/65/EU (RoHS) L174, 01.07.2011**

Furthermore, the safety objectives of the **Low Voltage Directive 2014/35/EU** as per Appendix I No.1.5.1 of Directive 2006/42/EC have been met.

Applied standards:

**DIN EN 60335-1:2020  
EN 60335-2-97:2017**

**EN 300220-2:2017  
EN 301489-3:2019**


**EN 62479:2011**

**EN 14202:2004**

Authorised party for the compilation of the technical documentation:  
Becker-Antriebe GmbH, Friedrich-Ebert-Str. 2 - 4, 35764 Sinn, Germany

This declaration of conformity was issued:

Sinn, 17.12.2021  
Place, Date

  
\_\_\_\_\_  
Jürgen Timm, Management

This declaration certifies compliance with the Directives cited but does not represent any assurance of characteristics. The safety warnings in the supplied product documentation must be observed!

K005\_en



**BECKER**



**BECKER**