

# P5-20...L120-11

## Model: S12

### **en** Assembly and Operating Instructions

## SMI tubular drives for sun protection systems

Important information for:

• Fitters / • Electricians / • Users

Please forward accordingly!

These instructions must be kept safe for future reference.

2010 300 887 of 27/02/2024

Becker-Antriebe GmbH  
Friedrich-Ebert-Straße 2-4  
35764 Sinn/Germany  
info@becker-antriebe.com  
www.becker-antriebe.com



**BECKER**  
for you. forever.

## Table of contents

General .....	3
Warranty .....	3
Safety instructions .....	4
Instructions for the user .....	4
Instructions for installation and commissioning.....	4
Intended use .....	6
Assembling and disassembling the plug-in connecting cable.....	6
Assembly .....	7
Setting the limit positions using the programming unit.....	9
Changing the additional stop behaviour function with the programming unit .....	11
Deleting the limit positions using the programming unit .....	12
Setting the limit positions with Auto-Install.....	14
Obstacle detection.....	15
Activating/deactivating the additional fabric untensioning function with the programming unit.....	15
Activating/deactivating the additional fabric tensioning function with the programming unit .....	16
Information for the electrician .....	16
Disposal .....	17
Maintenance .....	17
Technical data dia. 35 .....	17
Technical data dia. 45 .....	17
Technical data dia. 58 .....	18
What to do if...?.....	19
Sample wiring diagram .....	20
Assignment table for the SMI tubular drives.....	21
Declaration of conformity .....	22

## General

These tubular drives are high-quality products with the following features:

- Optimised for sun protection applications
- Installation without stops is also possible (from extended point to retracted point)
- Automatic detection of limit positions thanks to intelligent electronic system with stop systems
- Tensile load is optimally adapted to the mechanical requirements of the sun protection system
- The limit positions do not have to be reset: Changes in the shading solution are accommodated automatically when using stop systems.
- Easy setting of limit positions by pushing a button on the programming unit
- Considerably reduced stop load, and thus considerably reduced fabric load
- Activate/deactivate the fabric untensioning function
- Activate/deactivate the fabric tensioning function
- Right or left hand installation
- Several drives can be operated in parallel
- Compatible with the comprehensive range of the drive manufacturer's control units
- Smooth operation of the system and the drive increases the service life
- For plug-in connecting cable
- Suitable for all KNX/SMI actuators from the drive manufacturer

Please observe these Assembly and Operating Instructions when installing and setting up the equipment.



The date of manufacture comes from the first four digits of the serial number.

The numbers 1 and 2 indicate the year and the numbers 3 and 4 indicate the calendar week.

Example: 34th calendar week in 2020

Ser. No.:	2034XXXXX
-----------	-----------

### Explanation of pictograms

	<b>CAUTION</b>	CAUTION indicates a hazardous situation which, if not avoided, could result in injury.
	<b>ATTENTION</b>	ATTENTION indicates measures that must be taken to avoid damage to property.
		Denotes user tips and other useful information.

## Warranty

Structural modifications and incorrect installation which are not in accordance with these and our other instructions can result in serious injuries, e.g., crushing of limbs. Therefore, structural modifications may only be carried out with our prior approval and strictly in accordance with our instructions, particularly the information contained in these Assembly and Operating Instructions. Any further processing of the products which does not comply with their intended use is not permitted.

The end product manufacturer and fitter have to ensure that all the relevant current statutory, official and, in particular, EMC regulations are adhered to during utilisation of our products, especially with regard to end product manufacture, installation and customer advice.

## Safety instructions

The following safety instructions and warnings are intended to avert hazards and to prevent property damage and personal injury.

### Instructions for the user

#### General information

- The drive must be disconnected from its power source during cleaning and maintenance and when replacing parts.
- All work, including maintenance and cleaning, on electrical installations as well as other system parts must always be performed by trained technicians, in particular qualified electricians.
- Children from the age of 8 years and persons with reduced physical, sensory or mental capabilities or lack of experience and/or knowledge may use these devices, provided they are supervised or have been instructed in the safe use of the device, and have understood the hazards involved. Children must not play with the device.
- Systems have to be checked regularly by authorised specialists for wear and damage.
- Always put damaged systems out of operation immediately until they are repaired by an authorised specialist.
- Do not operate equipment if people or objects are within the danger zone.
- Observe the danger zone of the equipment during operation.
- Ensure that there is adequate clearance (at least 40 cm) between moving parts and adjacent objects.



#### Caution

##### Safety instructions for avoiding serious injuries.

- **Crushing or shearing points must be avoided or protected.**

### Instructions for installation and commissioning

#### General information

- Observe the safety instructions in EN 60335-2-97. Please note that this list of safety instructions is not exhaustive, since it would be impossible for the standard to include all sources of danger. For example, the design of the operated product, the way the drive works in the situation it is installed in or even the way the end product is mounted in the end user's place of use cannot be taken into consideration by the drive manufacturer.  
If any questions or uncertainties regarding the safety instructions contained in the standard arise, please contact the manufacturer of the part or end product in question.
- All applicable standards and regulations for electrical installation must be complied with.
- All work, including maintenance and cleaning, on electrical installations as well as other system parts must always be performed by trained technicians, in particular qualified electricians.
- Only use spare parts, tools and accessory devices which have been approved by the drive manufacturer.  
Unapproved third-party products or modifications to the system and its accessories represent a risk to your safety and the safety of others. This means that the use of unapproved third-party products, or modifications which have not been agreed with or approved by us, are prohibited. We do not accept liability for damage or injury arising from such actions.
- Position switch with OFF presetting within sight of the driven product, but away from moving parts, at a height of over 1.5 m. This must not be publicly accessible.
- Permanently mounted control devices must be positioned where they can be seen.
- Rated torque and duty cycle must be suitable for the requirements of the driven product.  
Technical data - rated torque and service life can be found on the type plate of the tubular drive.
- Hazardous moving parts of the drive must be installed at a height of over 2.5 m above floor level or any other surface from which the drive can be accessed.
- To ensure safe operation of the system after commissioning, the limit positions must be correctly set/programmed in.
- Drives with a H05VV-F connecting cable may only be used indoors.
- Drives with a H05RR-F, S05RN-F or 05RN-F connecting cable may be used both indoors and outdoors.
- To connect the drive to the driven part, solely mechanical accessory components made by the drive manufacturer from the current product catalogue may be used. The components must be installed in accordance with the manufacturer's instructions.

- If the drive is used for shading solutions in a specially marked area (e.g., escape routes, hazard zones, safety areas), compliance with all applicable regulations and standards must be ensured.
- Once the drive has been installed, the fitter must mark the used tubular drive in the “Technical data” chapter and make a note of the installation position.



#### **Caution**

##### **Safety instructions for avoiding serious injuries.**

- **When electrical or electronic equipment and units are operated, certain components, e.g., the power supply unit, are live. Physical injuries or damage to property can result in the event of unauthorised interventions or failure to heed warnings.**
- **Be careful when touching the tubular drive, as it heats up during operation for technical reasons.**
- **Before installation, shut down all lines and control devices that are not essential for operation.**
- **Crushing or shearing points must be avoided or protected.**
- **When installing the drive, all-pole disconnection from the mains with a contact gap of at least 3 mm per pole must be provided (EN 60335).**
- **If the mains connecting cable is damaged, it may only be replaced by the manufacturer. If the drive has a plug-in connecting cable, it must be replaced with the same type of mains connecting cable, which is available from the drive manufacturer.**

#### **Attention**

##### **Safety instructions for avoiding property damage.**

- **Ensure that there is adequate clearance between moving parts and adjacent objects.**
- **The drive must not be carried by the mains connecting cable.**
- **All latching connections and fastening screws on the brackets must be checked to ensure that they are secure.**
- **Ensure that nothing rubs against the tubular drive, such as shading solution attachments, screws, etc.**
- **The drive must be fitted horizontally.**

## Intended use

The type of tubular drive described in these instructions is intended solely for the operation of awnings, cassette awnings, screens, drop-arm awnings and conservatory shades.

It may only be used in networked systems if all the individual drives are exactly synchronised and reach the limit positions at the same time.

When mounting connection parts on the drive dia. 35 mm PXX/XX, only use screws EJOT Delta PT 40x12 WN 5454 Torx (9900 000 545 4).

For roller shutter applications, please use only the types of tubular drive designed for this purpose.

This type of tubular drive is designed for use in single systems (one drive per barrel).

The tubular drive must not be used in potentially explosive areas.

The connecting cable is not suitable for transporting the drive. Always carry the drive by the housing tube.

Other applications, uses and modifications are not permitted in order to protect the safety of the users and others, since these actions can impair the system's safety and carry the risk of personal injury and property damage. The drive manufacturer does not accept liability for damages or injury arising from such actions.

Always observe the information in these instructions when operating or repairing the system. The drive manufacturer does not accept liability for damage or injury resulting from improper usage.

## Assembling and disassembling the plug-in connecting cable




### Caution

**The power supply to the connecting cable must be disconnected prior to assembly/disassembly.**

### Assembling the plug-in connecting cable

Ø35/Ø45/Ø58




1 = locating lug

Insert the **dead** connecting cable into the drive head until the locating lug clicks into place in the drive. If necessary, use a suitable flathead screwdriver to assist with insertion. Set the screwdriver into one of the two plug grooves provided for this purpose.

Check that the cable is properly engaged.

### Disassembling the plug-in connecting cable for tubular drives

Ø35



A = snap-in pin

Insert a suitable flathead screwdriver between the locating lug and the snap-in pin, so that the snap-in pin releases the locating lug from the plug.

Now you can pull out the connecting cable along with the flat-head screwdriver.

<b>Ø45/Ø58</b>	<p>Insert a suitable flathead screwdriver right into the recess of the locating latch, so that the latch releases the locating lug from the plug.</p> <p>Now you can pull out the connecting cable along with the flat-head screwdriver.</p>
A = locating latch	

## Assembly

### Assembling the drive

#### Attention


**To connect the drive to the driven part, solely mechanical accessory components made by the drive manufacturer from the current product catalogue may be used.**

Prior to mounting, the fitter must ensure that the masonry and the system being motorised are sufficiently robust (drive torque plus weight of the shading solution).



#### Caution

**Electrical connections may only be carried out by a qualified electrician. Prior to assembly, the power supply must be disconnected and secured. Please give the enclosed connection information to the responsible electrical contractor.**




Calculate the space required at the side (M) by measuring the drive head (1) and wall bracket (2). The clear dimension of the box (X) minus the space required at the side (M) and idler (G) gives the length (L) of the barrel:  $L = X - M - G$ .

The space required at the side (M) varies depending on the combination of drive and wall bracket.

Then mount the wall bracket and idler. Ensure that the barrel is aligned at right angles to the wall and that sufficient axial play is allowed for the mounted system.

### Assembling and disassembling the mounting pin




#### Ø45, Ø58


When pushed in, the mounting pin (2) locks automatically. To undo the mounting pin (2), push the tab washer (1) upwards and pull out the mounting pin (2).

### Assembling and disassembling the drive adapter


#### Fitting the ring onto the thrust ring




#### Assembling the drive adapter with safety catch on the drive shaft



#### Disassembling the drive adapter with safety catch on the drive shaft




## Mounting the drive in the tube




### For profile shafts:

In the case of some drive adapters, tolerances of the groove widths in different barrels can be offset by rotating the drive adapter into a different groove recess. These groove recesses have different sizes and allow the drive to fit exactly.



### For round shafts:

Measure the lug of the thrust ring (X, Y). Then notch the tube on the motor side, so the lug of the thrust ring can also be pushed into the shaft. There must be no play between the lug of the thrust ring and the shaft.



To ensure secure torque transmission for **round shafts**, we recommend screwing the drive adapter to the shaft (see the table below).

**Attention! When drilling into the barrel, never drill near the tubular drive!**

Size of drive [mm]	Drive adapter	Torque max. [Nm]	Fastening screws (4 units)
dia. 35-dia. 45	All	Up to 50	Self-tapping screw dia. 4.8 x 9.5 mm
dia. 58	Aluminium drive adapter	Up to 120	Countersunk screw M8 x 16 mm
dia. 58	Diecast drive adapter	Up to 120	Self-tapping screw dia. 6.3 x 13 mm

We also recommend screwing the idler to the barrel.

### Attention


**Do not hammer the tubular drive into the tube or drop it into the barrel!**



Assemble the tubular drive with the relevant ring (1) and drive adapter (2). If the ring has several grooves, select the groove which is a perfect fit and push the ring (1) onto the thrust ring.

Insert the tubular drive with the pre-assembled ring (1) and drive adapter (2) into the tube to achieve a form fit. Ensure that the ring and drive adapter are secure in the tube.

Mount the assembled unit comprising shaft, tubular drive and idler on the box and secure the drive with a splint or spring pin according to the type of wall bracket fixing.



### Lay the connecting cable

Lay the connecting cable up to the tubular drive, and fix. The connecting cable must not project into the winding chamber. The exterior antenna, if present, must not be shortened or damaged under any circumstances and must not project into the winding space. Cover any sharp edges.



# Setting the limit positions using the programming unit

## Intelligent installation management

### Completion of installation following automatic setting of limit position "Stop"

Next time the "stop" limit position is travelled to, this position will be provisionally saved as the limit position. Once the limit position has been detected at this position 3 times in a row without any problems, it will be definitively saved. This normally takes place during regular operation.

To complete installation quickly, it is sufficient to travel to the "stop" limit position 3 times in a row from approx. 20 cm.

### Limit position status indicator

A brief stopping and restarting indicates that no limit position has been set in that direction of movement.

## Setting the limit positions

There are several ways to set the limit positions:




- Extended point to retracted point
- Extended point to retracted stop
- Auto install

The limit position becomes fixed after the tubular drive has turned off **automatically** in the desired position three times.

**i** If the tubular drive switches off prematurely while extending/retracting, due to an obstruction, the obstruction can be cleared by extending/retracting the screen and removing the obstruction. The upper limit position can be set by extending/retracting again.

### Attention

The programming unit is only designed for the commissioning, not for continuous operation.

 <p>green/yellow PE</p> <p>blue N</p> <p>brown L</p> <p>black I+</p> <p>grey I-</p>	 <p>Programming button →</p> <p>←Up / retract button</p> <p>←Down / extend button</p>
 <p>1</p>	<p>1 = direction switch</p>


Connect the wires of the tubular drive to those of the same colour in the programming unit (Item No. 4935 200 034 0) and switch on the power supply.

Check the assignment of the direction of rotation before positioning the limit stops.

Press the retract or extend button

- ▷ The shading solution runs in the desired direction
- ▶ The running direction is OK.


If the shading solution runs in the wrong direction, the running direction must be changed. Proceed as follows:



Switch the direction switch (1) to the opposite position.

- ▷ The running direction will now have changed.

Check the running direction again.



**i** It is only possible to change the direction of rotation if no limit position has been set. It may be necessary to delete both limit positions in order to change the direction of rotation.

### Extended point to retracted point

**i** There is no shading solution length adjustment with this limit position setting.

		Open to the desired extended limit position.
	(M) 1x	Press the programming button of the programming unit for 3 seconds. <ul style="list-style-type: none"> <li>▷ The tubular drive acknowledges.</li> </ul>
		Then open to the desired retracted limit position.
	(M) 1x	Press the programming button of the programming unit for 3 seconds. <ul style="list-style-type: none"> <li>▷ The tubular drive acknowledges.</li> <li>▶ The limit positions are now set.</li> </ul>

### Extended point to retracted stop






		Open to the desired extended limit position.
	(M) 1x	Press the programming button of the programming unit for 3 seconds. <ul style="list-style-type: none"> <li>▷ The tubular drive acknowledges.</li> </ul>
		Then retract to the permanent upper stop. <ul style="list-style-type: none"> <li>▷ The tubular drive switches off automatically.</li> <li>▶ The limit positions are now set.</li> </ul>

## Changing the additional stop behaviour function with the programming unit

On delivery, the 35 diameter drive types have a reduced stop behaviour, and the 45 diameter and 58 diameter drive types have an increased stop behaviour.

Proceed as follows to change the stop behaviour:

**i** The "to retracted stop" limit position must be set in order to adjust the stop behaviour. The stop behaviour can be changed during the first 3 runs towards the stop.








		<p>Press the retract button in order to retract the sun protection system.</p>
		<p>While retracting, <b>also</b> press the programming button until the tubular drive switches off automatically at the stop, and continue holding the two buttons down until confirmation is complete.</p>
		<p>Confirmation is provided by one or two shifts.          1 shift = reduced stop behaviour          2 shifts = increased stop behaviour</p>

## Deleting the limit positions using the programming unit

**i** Connect the wires of the tubular drive to those of the same colour in the programming unit and switch on the power supply.  
Please pause for 1 sec after the last drive command before beginning the deletion sequence. Also leave a pause of 1 sec between the individual steps of the deletion sequence.

### Deleting a limit position when 2 limit positions are programmed






**i** Any additional functions that have been set are retained.

	
	<p>Open/close to the limit position to be deleted.</p>
	<p>Press the programming button and keep it pressed.</p>
	<p>Then press down the travel button and keep it pressed.</p>
	<p>Now release the programming button, but continue to keep the travel button pressed.</p>
	<p>Next press the programming button again.</p> <ul style="list-style-type: none"> <li>▷ The tubular drive acknowledges.</li> <li>▶ The limit position is now deleted.</li> </ul>

## Deleting both limit positions



Any additional functions that may have been set are deleted at the same time, or are reset to the factory default settings.

	<p>Open/close the shading solution to a point between the limit positions.</p>
	<p>Press the programming button and keep it pressed.</p>
	<p>Then press down the travel button and keep it pressed.</p>
	<p>Now release the programming button, but continue to keep the travel button pressed.</p>
	<p>(M) 2x</p> <p>Next press the programming button again.</p> <ul style="list-style-type: none"> <li>▷ The tubular drive confirms.</li> <li>▶ Both limit positions are deleted.</li> </ul>

## Setting the limit positions with Auto-Install

### Intelligent installation management

#### Completion of installation following automatic setting of limit position "Stop"

Next time the "stop" limit position is travelled to, this position will be provisionally saved as the limit position. Once the limit position has been detected at this position 3 times in a row without any problems, it will be definitively saved. This normally takes place during regular operation.

To complete installation quickly, it is sufficient to travel to the "stop" limit position 3 times in a row from approx. 20 cm.

#### Limit position status indicator

A brief stopping and restarting indicates that no limit position has been set in that direction of movement.

### Setting the limit positions

There are several ways to set the limit positions:

- Start point to retracted stop
- Auto point to retracted stop (only with articulated-arm awnings)



**These settings can be programmed using the programming unit.**

**These tubular drives are designed for short-time operation (for the operating mode, please see technical data).**

**The number of cycles an awning is capable of depends on the barrel diameter and awning extension.**

**The drive running time is cut short if the drive has not cooled down fully after the previous use.**

### Start point to retracted stop

		Use the operator control to move the sun protection system to the desired maximum projection. This must be at least 2.5 revolutions of the barrel away from the retracted limit position. At this time, it is still possible to amend the position.
		Stop the sun protection system at this point.
		Then, retract the sun protection system <b>without interruption</b> until the tubular drive switches off automatically.  Installation is now complete; electronic limit switching has saved the limit positions. As a final check, run the sun protection system to the two limit positions again.  To ensure that the limit position is reliably detected and the sun protection system is fully closed, the tubular drive pulls the cloth slightly more strongly during the installation.

## Auto point to retracted stop (only with articulated-arm awnings)

### Attention

Ensure that the cloth is not wound up the wrong way by the barrel.

		<p>Use the travel button on the operating control to extend the articulated-arm awning until the articulated arms are fully protracted and the cloth is lying loosely over them.</p>
		<p>Stop the articulated-arm awning at this point.</p>
		<p>Then, retract the articulated-arm awning <b>without interruption</b> until the tubular drive switches off automatically.</p> <p>Installation is now complete; electronic limit switching has saved the limit positions. As a final check, run the sun protection system to the two limit positions again.</p> <p>To ensure that the limit position is reliably detected and the sun protection system is fully closed, the tubular drive pulls the cloth slightly more strongly during the installation.</p>

## Obstacle detection



### Caution

Use of the drive's obstacle detection system as personal protection is not permitted. It has been designed exclusively to protect the sun protection system from being damaged.

If the drive is correctly installed, it switches off when it detects obstructions or fabric faults and tries to run past the obstruction a second time. If this fails, the drive switches off after the third attempt. The total number of attempts to complete a travel that has been started to the respective limit position is limited to 10 (distributed over several obstruction locations).

If reversing is interrupted, a further drive command is only possible in the direction of reversing. Move the fabric without interruption until the tubular drive stops automatically. It is now possible to travel in both directions again.

## Activating/deactivating the additional fabric untensioning function with the programming unit



The "to retracted stop" limit position must be set for the fabric untensioning function.









On delivery, the fabric tensioning function is deactivated on tubular drives with a diameter of 35 mm, and is activated on tubular drives with diameters of 45 mm and 58 mm.

		<p>To activate/deactivate it, move to the Retract limit position.</p>
		<p>Press the programming button for approx. 5 seconds.</p> <ul style="list-style-type: none"> <li>▶ Confirmation is provided by a shift.</li> <li>▶ The fabric untensioning function is now activated/deactivated.</li> </ul>





## Activating/deactivating the additional fabric tensioning function with the programming unit

This function is deactivated on delivery.

### Activating the fabric tensioning function

		To activate it, move to the Extend limit position.
		Press the programming button for approx. 5 seconds. ▷ Confirmation is provided by a shift.
		Now move to the position where the fabric has the desired tension.
		Press the programming button for approx. 5 seconds. ▷ Confirmation is provided by a shift. ▶ The fabric untensioning function is now active.

### Deactivating the fabric tensioning function

		To deactivate it, move to the fabric tensioning limit position.
		Press the programming button for approx. 5 seconds. ▷ Confirmation is provided by a shift. ▶ The fabric untensioning function is now deactivated.

## Information for the electrician

Tubular drives with electronic limit switching can be connected in parallel. The maximum switching contact load of the switching equipment (timer, relay control, switch, etc.) must be observed. To operate drives with electronic limit switching, only use switching elements (timers) that are **not** earthed via the drive. The outputs of the switching element must be potential-free in the neutral position.

Use external conductor L1 to control the up and down direction. Other devices or consumers (lamps, relays, etc.) must not be directly connected to the drive connecting cables. For this purpose, the drives and additional devices must be decoupled by relay controls.

When installing the drive, all-pole disconnection from the mains with a contact gap of at least 3 mm per pole must be provided. It is not permitted to continually operate the drives with the mains voltage set to I+/-I-. This connection configuration is only intended for the time it takes to carry out commissioning using the programming unit.

#### Attention

**Only use mechanically or electrically locked switching elements with a marked zero position! This also applies when drives with electronic and mechanical limit switching are used in the same system. The changeover time for switching the running direction must be at least 0.5 s. The switch and control must not execute simultaneous UP and DOWN commands. Protect the electrical connections from damp.**

**Once you have finished wiring everything to the control, ALWAYS check the right direction assignment of the drive to the control buttons UP and DOWN, EXTEND and RETRACT.**

**If the drive is to be operated with devices which contain sources of interference, the electrician must ensure suitable interference suppression for the relevant devices.**



## Disposal



The crossed-out bin symbol on the product indicates that the device is subject to mandatory disposal separate from household waste. This product must be handed over to a collection point for electrical and electronic equipment at the end of its service life. The packaging material must be disposed of properly.

## Maintenance

These drives are maintenance-free.

### Technical data dia. 35

Tubular drive	P5-20	P5-30	P9-16
Model	S12		
Type	C PS V1 SMI		
Rated torque [Nm]	5	5	9
Output speed [rpm]	20	30	16
Limit switch range	64 revolutions		
Supply voltage	230 V AC / 50 Hz		
Connected load [W]	115	115	110
Rated current consumption [A]	0.47	0.47	0.47
Operating mode	S2 4 min		
Degree of protection	IP 44		
Min. tube inside diameter [mm]	37		
Emission sound pressure level [dB(A)]	≤ 70		

### Technical data dia. 45

Tubular drive	R8-17	R12-17	R20-17	R30-17	R40-17	R50-11
Model	S12					
Type	C PS+ V1 SMI					
Rated torque [Nm]	8	12	20	30	40	50
Output speed [rpm]	17	17	17	17	17	11
Limit switch range	64 revolutions					
Supply voltage	230 V AC / 50 Hz					
Connected load [W]	100	110	160	210	260	240
Rated current consumption [A]	0.45	0.50	0.70	0.90	1.15	1.05
Operating mode	S2 4 min					
Degree of protection	IP 44					
Min. tube inside diameter [mm]	47					
Emission sound pressure level [dB(A)]	≤ 70					

## Technical data dia. 58

Tubular drive	L44-14*	L50-17	L60-11	L60-17
Model	S12			
Type	C PS+ V1 SMI			
Rated torque [Nm]	44	50	60	60
Output speed [rpm]	14	17	11	17
Limit switch range	64 revolutions			
Supply voltage	230 V AC / 50 Hz			
Connected load [W]	255	315	265	380
Rated current consumption [A]	1.20	1.40	1.20	1.75
Operating mode	S2 4 min			
Degree of protection	IP 44			
Min. tube inside diameter [mm]	60			
Emission sound pressure level [dB(A)]	≤ 70			

Tubular drive	L70-17	L80-11	L80-17*	L120-11
Model	S12			
Type	C PS+ V1 SMI			
Rated torque [Nm]	70	80	80	120
Output speed [rpm]	17	11	17	11
Limit switch range	64 revolutions			
Supply voltage	230 V AC / 50 Hz			
Connected load [W]	430	310	470	435
Rated current consumption [A]	1.90	1.40	2.10	1.90
Operating mode	S2 4 min			
Degree of protection	IP 44			
Min. tube inside diameter [mm]	60			
Emission sound pressure level [dB(A)]	≤ 70			


\*) This tubular drive is not yet available.

## What to do if...?

Problem	Remedy
Tubular drive overruns the limit position or does not reach the set limit position.	Repair electrical installation and re-program limit positions.
	Check electrical installation; remove external devices; reset limit positions.
	Stops have broken off or one or several attachments are broken. Repair system; reset tubular drive, then re-program limit positions.
Tubular drive stops arbitrarily; cannot be restarted in the same direction.	Use a more powerful tubular drive.
	Ensure that the sun protection system runs smoothly.
Tubular drive does not run in the right direction.	Tubular drive is overheated. The tubular drive is operational again after a few minutes.
	Tubular drive is faulty (does not work even after standing still for a long period of time). Replace the tubular drive.
	Clear and remove the obstruction and set the drive in the direction required.
	Check the electrical connection.
Tubular drive only runs for approx. 1 second.	Tubular drive is faulty. Replace the tubular drive.
The tubular drive switches off automatically before the first required limit position (lower limit position) is programmed.	Tubular drive has detected a torque increase. Clear and remove the obstruction. Then move past this position to the desired limit position.
When you attempt to set the limit positions using Auto-install, this does not work.	Close to the desired extended limit position and set a point.
The tubular drive does not function correctly in SMI mode.	Check the electrical connection.
In BUS mode, the tubular drive extends the sun protection with retract commands, or retracts the sun protection with extend commands.	Disconnect the tubular drive from the SMI BUS. Delete the limit positions, switch the direction switch to the opposite position and test the direction of travel with the programming unit. Re-program limit positions.

## Sample wiring diagram

### Controlling one/several drive(s) via a single KNX/SMI actuator



Central control of up to 8 drives possible



**Button operation is activated by turning the power supply on and off.**

**The drive permanently changes to SMI mode as soon as SMI bus voltage is detected on the I+ and I- lines.**

Technical information as well as the KNX product database can be found on our homepage [www.becker-antriebe.com](http://www.becker-antriebe.com)

**Assignment table for the SMI tubular drives**

Serial number of the drive (Consider applying a serial number sticker)	Place of installation	Direction of rotation assigned / limit positions programmed

Manufacturer’s code: 2 = Becker-Antriebe GmbH

<b>Project / customer</b>	<b>Room</b>

<b>Signature Project manager / building contractor</b>	<b>Signature Installing company</b>

This assignment table is also available to you on our website: [www.becker-antriebe.com](http://www.becker-antriebe.com) for the electronic work.

# Declaration of conformity

BECKER-ANTRIEBE GMBH  
Friedrich-Ebert-Str. 2 – 4  
35764 Sinn, Germany



**BECKER**

- Original -

## EU Declaration of Conformity

Document No.: **5100 310 005 0**

We hereby declare that the following product series

Product designation: **Tubular motor**

Type designation: **P3/30.., P4/16.., P4/17.., P5/16.., P5/30.., P5/20.., P9/16.., P13/9.., R4/17.., R7/17.., R7/85.., R8/17.., R12/11.., R12/17.., R15/17.., R20/11.., R20/17.., R25/17.., R30/11.., R30/17.., R40/11.., R40/17.., R50/3,5.., R50/11.., L44/14.., L50/11.., L50/17.., L60/11.., L60/17.., L70/17.., L80/11.., L80/17.., L100/11.., L120/11..**

Version: **C, EVO, M, HK, R, S, F, P, E, O, SMI, A0...Z9, mute, +**

From serial number: from **232300001**

complies with the applicable regulations of the following Directives:

**Directive 2006/42/EC (MD) L157, 09.06.2006**

**Directive 2014/30/EU (EMC) L96, 29.03.2014**

**Directive 2011/65/EU (RoHS) L174, 01.07.2011**

Furthermore, the safety objectives of the **Low Voltage Directive 2014/35/EU** as per Appendix I No.1.5.1 of Directive 2006/42/EC have been met.

Applied standards:

**DIN EN 60335-1:2020**

**DIN EN 60335-2-97:2017**

**EN 61000-6-1:2019**

**EN 61000-6-3:2022**


**EN 14202:2004**

Authorised party for the compilation of the technical documentation:  
Becker-Antriebe GmbH, Friedrich-Ebert-Str. 2 – 4, 35764 Sinn, Germany

This declaration of conformity was issued:

Sinn, 02.06.2023

Place, Date

  
\_\_\_\_\_  
Maik Wiegelmann, Management

This declaration certifies compliance with the Directives cited but does not represent any assurance of characteristics. The safety warnings in the supplied product documentation must be observed!

CE Antriebe M+E\_ 5100 310 005 0 \_de

### For UK-Markets:

The Declaration of Conformity can be provided upon request from Becker Motors Ltd., or can be downloaded on [www.beckermotors.co.uk](http://www.beckermotors.co.uk).

**UK  
CA**





**BECKER**  
for you. forever.